

OTC Rusticated Weatherboard

OTC Rusticated Nail Fix Weatherboard

OTC Rusticated Weatherboard 135 x 18mm Direct fixed	●			●		
OTC Rusticated Weatherboard 135 x 18mm Cavity fixed on Structural Batten	●			●		
OTC Rusticated Weatherboard 135 x 18mm Cavity fixed on Non-structural Batten		●			●	
OTC Rusticated Weatherboard 180 x 18mm Direct Fixed	●			●		
OTC Rusticated Weatherboard 180 x 18mm Cavity fixed on Structural Batten	●			●		
OTC Rusticated Weatherboard 180 x 18mm Cavity fixed on Non-Structural Batten		●			●	
<p>Paslode Installation Option 1 (Traditional Method) Tool: Standard Paslode FrameMaster fitted with No Mark Attachment</p> <ul style="list-style-type: none"> Fit JoltFast weatherboard guide to tool nose. Do not overdrive JoltFast nail - leave proud. Set Depth of drive so bottom of head is proud of surface of weatherboard - test to determine correct setting prior to commencing work. Board should be pressed firmly against framing members during fixing. Hand punch, prime, fill and sand prior to finish coats being applied. <p>Paslode Installation Option 2 Tool: Paslode FrameMaster tool fitted with JoltFast Driver Blade (404485M) and No Mark Attachment</p> <ul style="list-style-type: none"> Do not overdrive JoltFast nail. Set tool depth of drive so head is punched 2mm below timber surface when driven - test to determine correct setting prior to commencing work. Board should be pressed firmly against framing members during fixing. When driving nail below timber surface: <ul style="list-style-type: none"> Nail holes must be primed and filled immediately after fixing using OTC End Seal aerosol primer Or use a squeeze bottle applicator/brush with Oil Based Primer When driving below timber surface. Paslode FrameMaster tools require the installation of a specialist driver blade (404485M). See your local service agent for details. Hand punch the nail if needed for correct depth of drive and finishing appearance. <p>Please follow the steps as outlined in above options as best practice.</p>	<p>Paslode Impulise JoltFast 65 x 2.8mm HD Galv B20680</p>	<p>Paslode Impulise JoltFast 75 x 3.06mm HD Galv B20681/B20681V</p>	<p>Paslode Impulise JoltFast 90 x 3.06mm HD Galv B20682</p>	<p>Paslode Impulise JoltFast 65 x 2.8mm Stainless Steel B20685</p>	<p>Paslode Impulise JoltFast 75 x 3.06mm Stainless Steel B20683</p>	<p>Paslode Impulise JoltFast 90 x 3.06mm Stainless Steel B20684</p>

OTC Bevelback Weatherboard

Paslode Tools to Suit Fasteners

Paslode Impulse Powervent FrameMaster B20543P	●	●	●	●	●	●
Paslode JoltFast Cladding Guide B20543S	●	●	●	●	●	●

OTC Bevelback Nail Fix Weatherboard

OTC Bevelback Weatherboard 135 x 18mm or 142 x 18mm Direct fixed		●			●	
OTC Bevelback Weatherboard 135 x 18mm or 142 x 18mm Cavity fixed on Structural Batten		●			●	
OTC Bevelback Weatherboard 135 x 18mm or 142 x 18mm Cavity fixed on Non-structural Batten		●			●	
OTC Bevelback Weatherboard 180 x 18mm or 187 x 18mm Direct fixed		●			●	
OTC Bevelback Weatherboard 180 x 18mm or 187 x 18mm Cavity fixed on Structural Batten		●			●	
OTC Bevelback Weatherboard 180 x 18mm or 187 x 18mm Cavity fixed on Non-Structural Batten		●			●	
<p>Paslode Installation Option 1 (Traditional Method) Tool: Standard Paslode FrameMaster fitted with No Mark Attachment</p> <ul style="list-style-type: none"> Fit JoltFast weatherboard guide to tool nose. Do not overdrive JoltFast nail - leave proud. Set Depth of drive so bottom of head is proud of surface of weatherboard - test to determine correct setting prior to commencing work. Board should be pressed firmly against framing members during fixing. Hand punch, prime, fill and sand prior to finish coats being applied. <p>Paslode Installation Option 2 Tool: Paslode FrameMaster tool fitted with JoltFast Driver Blade (404485M) and No Mark Attachment</p> <ul style="list-style-type: none"> Do not overdrive JoltFast nail. Set tool depth of drive so head is punched 2mm below timber surface when driven - test to determine correct setting prior to commencing work. Board should be pressed firmly against framing members during fixing. When driving nail below timber surface: <ul style="list-style-type: none"> Nail holes must be primed and filled immediately after fixing using OTC End Seal aerosol primer Or use a squeeze bottle applicator/brush with Oil Based Primer When driving below timber surface. Paslode FrameMaster tools require the installation of a specialist driver blade (404485M). See your local service agent for details. Hand punch the nail if needed for correct depth of drive and finishing appearance. <p>Please follow the steps as outlined in above options as best practice.</p>	<p>Paslode Impulse JoltFast 65 x 2.8mm HD Galv B20680</p>	<p>Paslode Impulse JoltFast 75 x 3.06mm HD Galv B20681/B20681V</p>	<p>Paslode Impulse JoltFast 90 x 3.06mm HD Galv B20682</p>	<p>Paslode Impulse JoltFast 65 x 2.8mm Stainless Steel B20685</p>	<p>Paslode Impulse JoltFast 75 x 3.06mm Stainless Steel B20683</p>	<p>Paslode Impulse JoltFast 90 x 3.06mm Stainless Steel B20684</p>

OTC Vertical Shiplap Weatherboard

OTC Vertical Shiplap Weatherboard

OTC Vertical Shiplap Weatherboard 135 x 18mm Direct fixed	●			●		
OTC Vertical Shiplap Weatherboard 135 x 18mm Cavity fixed on Drained Structural Batten	●			●		
OTC Vertical Shiplap Weatherboard 135 x 18mm Cavity fixed on Drained Non-structural Batten		●			●	
OTC Vertical Shiplap Weatherboard 180 x 18mm Direct fixed	●			●		
OTC Vertical Shiplap Weatherboard 180 x 18mm Cavity fixed on Drained Structural Batten	●			●		
OTC Vertical Shiplap Weatherboard 180 x 18mm Cavity fixed on Drained Non-Structural Batten		●			●	
<p>Paslode Installation Option 1 (Traditional Method) Tool: Standard Paslode FrameMaster fitted with No Mark Attachment</p> <ul style="list-style-type: none"> Fit JoltFast weatherboard guide to tool nose. Do not overdrive JoltFast nail - leave proud. Set Depth of drive so bottom of head is proud of surface of weatherboard - test to determine correct setting prior to commencing work. Board should be pressed firmly against framing members during fixing. Hand punch, prime, fill and sand prior to finish coats being applied. <p>Paslode Installation Option 2 Tool: Paslode FrameMaster tool fitted with JoltFast Driver Blade (404485M) and No Mark Attachment</p> <ul style="list-style-type: none"> Do not overdrive JoltFast nail. Set tool depth of drive so head is punched 2mm below timber surface when driven - test to determine correct setting prior to commencing work. Board should be pressed firmly against framing members during fixing. When driving nail below timber surface: <ul style="list-style-type: none"> Nail holes must be primed and filled immediately after fixing using OTC End Seal aerosol primer Or use a squeeze bottle applicator/brush with Oil Based Primer When driving below timber surface. Paslode FrameMaster tools require the installation of a specialist driver blade (404485M). See your local service agent for details. Hand punch the nail if needed for correct depth of drive and finishing appearance. <p>Please follow the steps as outlined in above options as best practice.</p>	<p>Paslode Impulse JoltFast 65 x 2.8mm HD Galv B20680</p>	<p>Paslode Impulse JoltFast 75 x 3.06mm HD Galv B20681/B20681V</p>	<p>Paslode Impulse JoltFast 90 x 3.06mm HD Galv B20682</p>	<p>Paslode Impulse JoltFast 65 x 2.8mm Stainless Steel B20685</p>	<p>Paslode Impulse JoltFast 75 x 3.06mm Stainless Steel B20683</p>	<p>Paslode Impulse JoltFast 90 x 3.06mm Stainless Steel B20684</p>